

Digitale Kabelprogrammliste geortnet nach Alphabet 12.12.2023

Name des Senders	Kanal / Frequenz	Symbol	QAM	Transp.	Sparte
1-2-3.tv	C41 / 634Mhz	6900	256	19°TP7	TV
1Live	S28 / 362Mhz	6900	256	19°TP7	TV
1Live diGGi	S28 / 362Mhz	6900	256	19°TP7	TV
3sat HD	S26 / 346 Mhz	6900	256	19°TP7	TV
3sat	C34 / 578Mhz	6900	256	19°TP7	TV
4MEDIATHEK	C26 / 514Mhz	6900	256	19°TP7	Radio
4mediathek	C39 / 618Mhz	6900	256	19°TP19	TV
Al Jazeera Balka	C47 / 682Mhz	6900	256	19°TP19	TV
Algerie 3	C49 / 698Mhz	6900	256	19°TP19	TV
ALT Sendersuchla	C38 / 610Mhz	6900	256	19°TP19	TV
AMC Balkan	C47 / 682Mhz	6900	256	19°TP5	TV
ANIXE HD	C40 / 626Mhz	6900	256	19°TP5	TV
ANIXE+	C41 / 634Mhz	6900	256	19°TP5	TV
ANTENNE BAYERN	C35 / 586Mhz	6900	256	19°TP5	TV
Antenne Brbg.	C37 / 602Mhz	6900	256	19°TP5	TV
ARD-alpha HD	S28 / 362Mhz	6900	256	19°TP5	TV
arte HD	S22 / 314Mhz	6900	256	19°TP5	TV
AstroTV HD	C26 / 514Mhz	6900	256	19°TP5	TV
AstroTV	C42 / 642Mhz	6900	256	19°TP5	TV
ATV HD	S25 / 338Mhz	6900	256	19°TP5	TV
ATV	C28 / 530Mhz	6900	256	19°TP5	TV
ATV2 HD	S25 / 338Mhz	6900	256	19°TP5	TV
Babestation24	C38 / 610Mhz	6900	256	19°TP5	TV
Baden TV	C42 / 642Mhz	6900	256	19°TP5	TV
Bayern 1	S28 / 362Mhz	6900	256	19°TP5	TV
Bayern 2	S28 / 362Mhz	6900	256	19°TP5	TV
Bayern 3	S28 / 362Mhz	6900	256	19°TP11	TV
Bibel TV HD	S25 / 338Mhz	6900	256	19°TP11	TV
Bibel TV	C49 / 698Mhz	6900	256	19°TP3	TV
BN Music HD	C47 / 682Mhz	6900	256	19°TP3	TV
BN SAT HD	C47 / 682Mhz	6900	256	19°TP3	TV
Bobar Radio	C47 / 682Mhz	6900	256	19°TP3	TV
Bobar Radio	C47 / 682Mhz	6900	256	19°TP3	TV
BR Fernsehen Nor	C31 / 554Mhz	6900	256	19°TP3	TV
BR Fernsehen Nor HD	S27 / 354Mhz	6900	256	19°TP3	TV
BR Fernsehen Süd	C31 / 554Mhz	6900	256	19°TP3	TV

BR Fernsehen Süd HD	S27 / 354Mhz	6900	256	19°TP3	TV
BR Schlager	S28 / 362Mhz	6900	256	19°TP10	TV
BR_Klassik	S28 / 362Mhz	6900	256	19°TP10	TV
BR24	S28 / 362Mhz	6900	256	19°TP10	TV
Bremen Eins	S28 / 362Mhz	6900	256	19°TP25	TV
Bremen next	S28 / 362Mhz	6900	256	19°TP25	TV
Bremen Vier	S28 / 362Mhz	6900	256	19°TP25	TV
Bremen Zwei	S28 / 362Mhz	6900	256	19°TP25	TV
BR-Heimat	S28 / 362Mhz	6900	256	19°TP25	TV
BRlive	S28 / 362Mhz	6900	256	19°TP25	TV
BunnyClub24	C38 / 610Mhz	6900	256	19°TP25	TV
Canal Algerie	C49 / 698Mhz	6900	256	19°TP39	TV
Channel21	C35 / 586Mhz	6900	256	19°TP39	TV
Cherie 25	C49 / 698Mhz	6900	256	19°TP39	TV
Cherie 25	C49 / 698Mhz	6900	256	19°TP39	TV
Clipmobile	C38 / 610Mhz	6900	256	19°TP39	TV
Cosmo	S28 / 362Mhz	6900	256	19°TP39	Radio
Das Erste HD	S22 / 314Mhz	6900	256	19°TP39	Radio
Das Erste	C31 / 554Mhz	6900	256	19°TP39	Radio
DASDING	S28 / 362Mhz	6900	256	19°TP39	Radio
DateLine	C38 / 610Mhz	6900	256	19°TP39	Radio
DELUXE MUSIC	C35 / 586Mhz	6900	256	19°TP39	Radio
Deutsches Musik	C38 / 610Mhz	6900	256	19°TP39	Radio
Die Maus	S28 / 362Mhz	6900	256	19°TP39	Radio
Disney Channel	C41 / 634Mhz	6900	256	19°TP39	Radio
Dlf Kultur	C34 / 578Mhz	6900	256	19°TP39	Radio
Dlf Nova	C34 / 578Mhz	6900	256	19°TP39	Radio
Dlf	C34 / 578Mhz	6900	256	19°TP39	Radio
DMAX Austria	C35 / 586Mhz	6900	256	19°TP39	Radio
DMAX HD Austria	C25 / 506Mhz	6900	256	19°TP39	Radio
DMAX HD	C25 / 506Mhz	6900	256	19°TP39	Radio
DMAX	C42 / 642Mhz	6900	256	19°TP39	Radio
DM-SAT	C51 / 714Mhz	6900	256	19°TP39	Radio
DRadio DokDeb	C34 / 578Mhz	6900	256	19°TP39	Radio
Dreamgirls24 TV	C38 / 610Mhz	6900	256	19°TP39	Radio
Duga Plus	C47 / 682Mhz	6900	256	19°TP39	Radio
egoFM	C41 / 634Mhz	6900	256	19°TP39	Radio
Ennstal-TV	C46 / 674Mhz	6900	256	19°TP39	Radio
EROTIKA TV - NEU	C38 / 610Mhz	6900	256	19°TP39	Radio
Erotiksat24 TV t	C38 / 610Mhz	6900	256	19°TP39	Radio
Eurosport 1 Deut	C29 / 538Mhz	6900	256	19°TP39	Radio
EWTN katholische	C41 / 634Mhz	6900	256	19°TP39	Radio
ffn	C38 / 610Mhz	6900	256	19°TP39	Radio
Flimmit	S23 / 322Mhz	6900	256	19°TP39	Radio

FM4	C26 / 514Mhz	6900	256	19°TP39	Radio
FOLX MUSIC TELEV	C35 / 586Mhz	6900	256	19°TP39	Radio
Fotohandy	C38 / 610Mhz	6900	256	19°TP39	Radio
Fritz	C37 / 602Mhz	6900	256	19°TP39	Radio
GayBoys LIVE	C38 / 610Mhz	6900	256	19°TP39	Radio
Genius exklusiv	C35 / 586Mhz	6900	256	19°TP39	Radio
Genius Plus	C40 / 626Mhz	6900	256	19°TP39	Radio
Genius Trend	C42 / 642Mhz	6900	256	19°TP39	Radio
Handystar TV 2	C42 / 642Mhz	6900	256	19°TP39	Radio
Handystar TV	C41 / 634Mhz	6900	256	19°TP39	Radio
Heiss und Sexy T	C38 / 610Mhz	6900	256	19°TP39	Radio
HITRADIO OE3	C28 / 530Mhz	6900	256	19°TP39	Radio
HKR	C48 / 690Mhz	6900	256	19°TP39	Radio
Hope TV	S25 / 338Mhz	6900	256	19°TP39	Radio
hr1	C37 / 602Mhz	6900	256	19°TP39	Radio
hr2	C37 / 602Mhz	6900	256	19°TP39	Radio
hr3	C37 / 602Mhz	6900	256	19°TP39	Radio
hr4	C37 / 602Mhz	6900	256	19°TP43	Sky Abo
hr-fernsehen HD	C37 / 602Mhz	6900	256	19°TP47	Sky Abo
hr-fernsehen	C31 / 554Mhz	6900	256	19°TP67	Sky Abo
hr-INFO	C37 / 602Mhz	6900	256	19°TP69	Sky Abo
HRT-HR1	C48 / 690Mhz	6900	256	19°TP75	Sky Abo
HRT-HR2	C48 / 690Mhz	6900	256	19°TP79	Sky Abo
HRT-HR3	C48 / 690Mhz	6900	256	19°TP81	Sky Abo
HRTInt. HD	C48 / 690Mhz	6900	256	19°TP95	Sky Abo
HRT-TV1 HD	C48 / 690Mhz	6900	256	19°TP99	Sky Abo
HRT-TV2 HD	C48 / 690Mhz	6900	256	19°TP85	TV
HRT-TV3 HD	C48 / 690Mhz	6900	256	19°TP85	TV
HRT-TV4 HD	C48 / 690Mhz	6900	256	19°TP85	TV
HSE HD	C40 / 626Mhz	6900	256	19°TP85	TV
HSE SD	C42 / 642Mhz	6900	256	19°TP85	TV
HSE24 EXTRA	C29 / 538Mhz	6900	256	19°TP85	TV
HSE24 TREND SD	C42 / 642Mhz	6900	256	19°TP85	TV
Immer etwas Neue	C35 / 586Mhz	6900	256	19°TP85	TV
JAM FM	C41 / 634Mhz	6900	256	19°TP85	TV
Juwelo HD	C25 / 506Mhz	6900	256	19°TP85	TV
JuweloTV	C38 / 610Mhz	6900	256	19°TP101	TV
Kabel 1 Austria	C30 / 546Mhz	6900	256	19°TP101	TV
Kabel 1 Schweiz	C30 / 546Mhz	6900	256	19°TP101	TV
kabel eins class	C39 / 618Mhz	6900	256	19°TP101	TV
kabel eins Doku	C36 / 594Mhz	6900	256	19°TP101	TV
kabel eins	C36 / 594Mhz	6900	256	19°TP101	TV
kabel1 Doku aust	C39 / 618Mhz	6900	256	19°TP101	TV
KiKA HD	S26 / 346 Mhz	6900	256	19°TP101	TV

KiKA	C34 / 578Mhz	6900	256	19°TP101	TV
Klassik Radio	C41 / 634Mhz	6900	256	16° TP123	TV
krone.tv	S23 / 322Mhz	6900	256	16° TP123	TV
K-TV	C38 / 610Mhz	6900	256	16° TP123	TV
KURIER TV	S25 / 338Mhz	6900	256	19°TP109	TV
Liezen TV	C46 / 674Mhz	6900	256	19°TP109	TV
LT1-OOE	C26 / 514Mhz	6900	256	19°TP109	TV
L-TV	C26 / 514Mhz	6900	256	19°TP109	TV
Maennersache TV	C38 / 610Mhz	6900	256	19°TP109	TV
MDR aktuell	C37 / 602Mhz	6900	256	19°TP109	TV
MDR JUMP	C37 / 602Mhz	6900	256	19°TP109	TV
MDR KLASSIC	C37 / 602Mhz	6900	256	19°TP115	TV
MDR KULTUR	C37 / 602Mhz	6900	256	19°TP115	TV
MDR Sachsen DD	C37 / 602Mhz	6900	256	19°TP115	TV
MDR Sachsen HD	C37 / 602Mhz	6900	256	19°TP115	TV
MDR Sachsen	C22 / 482Mhz	6900	256	19°TP115	TV
MDR S-Anhalt HD	C37 / 602Mhz	6900	256	19°TP115	TV
MDR S-Anhalt MD	C37 / 602Mhz	6900	256	19°TP115	TV
MDR S-Anhalt	C22 / 482Mhz	6900	256	19°TP115	TV
MDR SPUTNIK	C37 / 602Mhz	6900	256	19°TP115	TV
MDR THÜR Mitte W	C37 / 602Mhz	6900	256	19°TP115	TV
MDR Thüringen HD	C37 / 602Mhz	6900	256	19°TP115	Radio
MDR Thüringen HD	C37 / 602Mhz	6900	256	19°TP115	Radio
MDR Thüringen	C22 / 482Mhz	6900	256	19°TP115	Radio
MediaShop- Meine	C35 / 586Mhz	6900	256	19°TP115	Radio
MediaShop- Neuhe	C42 / 642Mhz	6900	256	19°TP115	Radio
meinTVshop	S23 / 322Mhz	6900	256	19°TP115	Radio
meinTVshop	C42 / 642Mhz	6900	256	19°TP115	Radio
Melodie TV NEU	S23 / 322Mhz	6900	256	19°TP115	Radio
Mobile Sex	C38 / 610Mhz	6900	256	19°TP115	Radio
N24 DOKU	C41 / 634Mhz	6900	256	19°TP115	Radio
NDR 1 Nieders. H	S28 / 362Mhz	6900	256	19°TP115	Radio
NDR 1 Radio MV S	S28 / 362Mhz	6900	256	19°TP115	Radio
NDR 2 NDS	S28 / 362Mhz	6900	256	19°TP115	Radio
NDR 90,3	S28 / 362Mhz	6900	256	19°TP115	Radio
NDR Blue	S28 / 362Mhz	6900	256	19°TP117	TV
NDR FS HH HD	S27 / 354Mhz	6900	256	19°TP117	TV
NDR FS HH	C22 / 482Mhz	6900	256	19°TP117	TV
NDR FS MV HD	S27 / 354Mhz	6900	256	19°TP117	TV
NDR FS MV	C22 / 482Mhz	6900	256	19°TP117	TV
NDR FS NDS HD	S27 / 354Mhz	6900	256	19°TP117	TV
NDR FS NDS	C22 / 482Mhz	6900	256	19°TP117	TV
NDR FS SH HD	S27 / 354Mhz	6900	256	19°TP117	TV
NDR FS SH	C22 / 482Mhz	6900	256	19°TP117	TV

NDR Info NDS	S28 / 362Mhz	6900	256	19°TP117	TV
NDR Info Spezial	S28 / 362Mhz	6900	256	19°TP117	TV
NDR Kultur	S28 / 362Mhz	6900	256	19°TP117	TV
NDR Schlager	S28 / 362Mhz	6900	256	19°TP117	TV
NDR1 Welle Nord	S28 / 362Mhz	6900	256	19°TP117	TV
Nick/Comedy Cent	C35 / 586Mhz	6900	256	19°TP117	TV
NITRO	C52 / 722Mhz	6900	256	19°TP117	TV
NITRO Austria	C26 / 514Mhz	6900	256	19°TP117	TV
N-JOY	S28 / 362Mhz	6900	256	19°TP117	TV
NRJ 12	C49 / 698Mhz	6900	256	19°TP117	TV
NRJ 12	C49 / 698Mhz	6900	256	19°TP117	TV
n-tv Austria	C28 / 530Mhz	6900	256	19°TP91	TV
n-tv	C52 / 722Mhz	6900	256	19°TP91	TV
OE1 DD	C26 / 514Mhz	6900	256	19°TP91	TV
OE1	C26 / 514Mhz	6900	256	19°TP91	TV
OE2 B	C26 / 514Mhz	6900	256	19°TP91	TV
OE2 K	C26 / 514Mhz	6900	256	19°TP91	TV
OE2 N	C26 / 514Mhz	6900	256	19°TP91	TV
OE2 O	C26 / 514Mhz	6900	256	19°TP82	TV
OE2 S	C26 / 514Mhz	6900	256	19°TP82	TV
OE2 St	C26 / 514Mhz	6900	256	19°TP82	TV
OE2 T	C26 / 514Mhz	6900	256	19°TP82	TV
OE2 V	C26 / 514Mhz	6900	256	19°TP82	TV
OE2 W	C26 / 514Mhz	6900	256	19°TP82	TV
oe24.TV HD	S23 / 322Mhz	6900	256	19°TP82	TV
OE3	C26 / 514Mhz	6900	256	19°TP82	TV
OE3.	S21 / 306Mhz	6900	256	19°TP82	TV
ONE HD	S28 / 362Mhz	6900	256	19°TP82	TV
ORF III HD	S23 / 322Mhz	6900	256	19°TP71	TV
ORF III	C26 / 514Mhz	6900	256	19°TP71	TV
ORF SPORT+ HD	S23 / 322Mhz	6900	256	19°TP71	TV
ORF SPORT+	S25 / 338Mhz	6900	256	19°TP71	TV
ORF1 HD	S21 / 306Mhz	6900	256	19°TP71	TV
ORF1	C28 / 530Mhz	6900	256	19°TP71	TV
ORF2 B	C28 / 530Mhz	6900	256	19°TP77	TV
ORF2 K	C28 / 530Mhz	6900	256	19°TP77	TV
ORF2 N	C28 / 530Mhz	6900	256	19°TP77	TV
ORF2 O	C28 / 530Mhz	6900	256	19°TP77	TV
ORF2 S	C28 / 530Mhz	6900	256	19°TP77	TV
ORF2 St	C28 / 530Mhz	6900	256	19°TP77	Radio
ORF2 T	C28 / 530Mhz	6900	256	19°TP77	Radio
ORF2 V	C28 / 530Mhz	6900	256	19°TP77	Radio
ORF2 W	C28 / 530Mhz	6900	256	19°TP77	Radio
ORF2	C28 / 530Mhz	6900	256	19°TP87	TV

ORF2B HD	S23 / 322Mhz	6900	256	19°TP87	TV
ORF2E	C28 / 530Mhz	6900	256	19°TP87	TV
ORF2K HD	S23 / 322Mhz	6900	256	19°TP87	TV
ORF2N HD	S21 / 306Mhz	6900	256	19°TP87	TV
ORF2O HD	S23 / 322Mhz	6900	256	19°TP87	TV
ORF2S HD	S23 / 322Mhz	6900	256	19°TP87	TV
ORF2St HD	S23 / 322Mhz	6900	256	19°TP87	TV
ORF2T HD	S23 / 322Mhz	6900	256	19°TP87	TV
ORF2V HD	S23 / 322Mhz	6900	256	19°TP87	TV
ORF2W HD	S21 / 306Mhz	6900	256	19°TP87	Radio
Panorama Haus	C46 / 674Mhz	6900	256	19°TP87	Radio
pearl.tv HD Shop	C25 / 506Mhz	6900	256	19°TP87	Radio
pearl.tv Shop	C35 / 586Mhz	6900	256	19°TP107	TV
phoenix HD	S27 / 354Mhz	6900	256	19°TP107	TV
PLANAI Prog 2	C46 / 674Mhz	6900	256	19°TP107	TV
PLANAI Prog 3	C46 / 674Mhz	6900	256	19°TP107	TV
Pro7 MAXX Austri	C39 / 618Mhz	6900	256	19°TP107	TV
Pro7 MAXX	C36 / 594Mhz	6900	256	19°TP107	TV
ProSieben Austria	C30 / 546Mhz	6900	256	19°TP107	TV
ProSieben HD Aus	C39 / 618Mhz	6900	256	19°TP107	TV
ProSieben Schweiz	C30 / 546Mhz	6900	256	19°TP107	TV
ProSieben	C36 / 594Mhz	6900	256	19°TP107	TV
PULS	S28 / 362Mhz	6900	256	19°TP61	TV
PULS 24 HD	C39 / 618Mhz	6900	256	19°TP61	TV
PULS 4 Austria	C30 / 546Mhz	6900	256	19°TP61	TV
PULS 4 HD Austri	C39 / 618Mhz	6900	256	19°TP61	TV
QVC Deutschland	C49 / 698Mhz	6900	256	19°TP61	TV
QVC HD	C40 / 626Mhz	6900	256	19°TP61	TV
QVC	C41 / 634Mhz	6900	256	19°TP61	Radio
QVC2	C49 / 698Mhz	6900	256	19°TP61	Radio
R9 Oesterreich H	S23 / 322Mhz	6900	256	19°TP61	Radio
Radio BIR	C47 / 682Mhz	6900	256	19°TP61	Radio
Radio BN	C47 / 682Mhz	6900	256	19°TP61	Radio
Radio Bremen HD	S28 / 362Mhz	6900	256	19°TP61	Radio
Radio Bremen TV	C23 / 490Mhz	6900	256	19°TP61	Radio
Radio Gloria	C38 / 610Mhz	6900	256	19°TP61	Radio
Radio HBR	C38 / 610Mhz	6900	256	19°TP61	Radio
Radio HCJB	C38 / 610Mhz	6900	256	19°TP61	Radio
RADIO MARIA	C26 / 514Mhz	6900	256	19°TP61	Radio
Radio Mir Medjug	C47 / 682Mhz	6900	256	19°TP61	Radio
Radio Mix	C47 / 682Mhz	6900	256	19°TP61	Radio
Radio Paloma	C38 / 610Mhz	6900	256	19°TP61	Radio
Radio Stari Grad	C47 / 682Mhz	6900	256	19°TP61	Radio
radioeins	C37 / 602Mhz	6900	256	19°TP61	Radio

Rai Radio 2	C54 / 738Mhz	6900	256	19°TP61	Radio
Rai Visual	C54 / 738Mhz	6900	256	19°TP61	Radio
Rai yoyo HD	C54 / 738Mhz	6900	256	19°TP61	Radio
RASLO ARS	C48 / 690Mhz	6900	256	19°TP61	Radio
RASLO PRVI	C48 / 690Mhz	6900	256	19°TP61	Radio
RASLO RADIO SI	C48 / 690Mhz	6900	256	19°TP113	TV
RASLO VAL 202	C48 / 690Mhz	6900	256	19°TP113	TV
rbb 88.8	C37 / 602Mhz	6900	256	19°TP113	TV
rbb Berlin HD	C37 / 602Mhz	6900	256	19°TP113	TV
rbb Berlin	C22 / 482Mhz	6900	256	19°TP113	TV
rbb Brandenburg HD	C37 / 602Mhz	6900	256	19°TP113	TV
rbb Brandenburg	C22 / 482Mhz	6900	256	19°TP113	TV
rbb24 Inforadio	C37 / 602Mhz	6900	256	19°TP113	TV
REGIO TV	C42 / 642Mhz	6900	256	19°TP113	TV
rhein main tv	C38 / 610Mhz	6900	256	19°TP113	TV
RiC	C28 / 530Mhz	6900	256	19°TP113	TV
RM Albania	C47 / 682Mhz	6900	256	19°TP113	TV
RM BiH	C47 / 682Mhz	6900	256	19°TP113	TV
RM Hungary	C47 / 682Mhz	6900	256	19°TP113	TV
RM Kosovo	C47 / 682Mhz	6900	256	19°TP113	TV
RM Romania HU	C47 / 682Mhz	6900	256	19°TP113	TV
RM Romania RO	C47 / 682Mhz	6900	256	19°TP113	TV
RM Serbia HU	C47 / 682Mhz	6900	256	19°TP113	TV
RM Serbia SRB	C47 / 682Mhz	6900	256	19°TP113	TV
ROCK ANTENNE	C35 / 586Mhz	6900	256	19°TP113	Radio
rrbKultur	C37 / 602Mhz	6900	256	19°TP113	Radio
RTL Austria	C29 / 538Mhz	6900	256	19°TP113	Radio
RTL Bayern	C52 / 722Mhz	6900	256	19°TP113	Radio
RTL HB NDS	C52 / 722Mhz	6900	256	19°TP113	Radio
RTL HH SH	C52 / 722Mhz	6900	256	19°TP113	Radio
RTL Regional NRW	C52 / 722Mhz	6900	256	19°TP113	Radio
RTL Television	C52 / 722Mhz	6900	256	19°TP31	TV
RTL2 Austria	C29 / 538Mhz	6900	256	19°TP31	TV
RTLup	C52 / 722Mhz	6900	256	19°TP31	TV
RTLup Austria	S25 / 338Mhz	6900	256	19°TP31	TV
RTLZWEI	C52 / 722Mhz	6900	256	19°TP31	TV
RTS Un HD	C24 / 498Mhz	6900	256	19°TP31	TV
SAT.1 A	C30 / 546Mhz	6900	256	19°TP31	TV
SAT.1 Bayern	C36 / 594Mhz	6900	256	19°TP31	TV
SAT.1 CH	C30 / 546Mhz	6900	256	19°TP31	TV
SAT.1 emotions	C39 / 618Mhz	6900	256	19°TP31	TV
SAT.1 Gold Öster	C39 / 618Mhz	6900	256	19°TP31	TV
SAT.1 Gold	C36 / 594Mhz	6900	256	19°TP53	TV
SAT.1 HD Austria	C39 / 618Mhz	6900	256	19°TP53	TV

SAT.1 HH/SH	C30 / 546Mhz	6900	256	19°TP53	TV
SAT.1 NRW	C36 / 594Mhz	6900	256	19°TP53	TV
SAT.1 NS/Bremen	C30 / 546Mhz	6900	256	19°TP53	TV
SAT.1 RhIPf/Hess	C30 / 546Mhz	6900	256	19°TP53	TV
SAT.1	C36 / 594Mhz	6900	256	19°TP53	TV
SBN International	C49 / 698Mhz	6900	256	19°TP103	TV
Schladming-Dachst.	C46 / 674Mhz	6900	256	19°TP103	TV
Schlager Radio	C38 / 610Mhz	6900	256	19°TP103	TV
Schlager Radio	C38 / 610Mhz	6900	256	19°TP103	TV
Schlager Radio	C38 / 610Mhz	6900	256	19°TP103	TV
ServusTV Deutsch	C26 / 514Mhz	6900	256	19°TP103	TV
ServusTV HD Deut	S21 / 306Mhz	6900	256	19°TP103	TV
ServusTV HD Oest	S21 / 306Mhz	6900	256	19°TP103	TV
ServusTV Oesterr	C26 / 514Mhz	6900	256	19°TP103	TV
Shop LC	C26 / 514Mhz	6900	256	19°TP103	Radio
ShopLC HD	C40 / 626Mhz	6900	256	19°TP103	Radio
sixx	C36 / 594Mhz	6900	256	19°TP103	Radio
SIXX	C41 / 634Mhz	6900	256	19°TP104	TV
sixx AUSTRIA	C39 / 618Mhz	6900	256	19°TP104	TV
SKY TP 43 Sky ABO	S30 / 378Mhz	6900	256	19°TP104	TV
SKY TP47 SKY ABO	S31 / 386 Mhz	6900	256	19°TP104	TV
SKY TP67 SKY ABO	S33 / 402Mhz	6900	256	19°TP104	TV
SKY TP69 SKY ABO	S34 / 410Mhz	6900	256	19°TP104	TV
SKY TP75 SKY ABO	S36 / 426Mhz	6900	256	19°TP104	TV
SKY TP79 SKY ABO	S37 / 434Mhz	6900	256	19°TP104	TV
SKY TP81 SKY ABO	S38 / 442Mhz	6900	256	19°TP104	TV
SKY TP95 SKY ABO	S40 / 458Mhz	6900	256	19°TP104	TV
SKY TP99 SKY ABO	S41 / 466Mhz	6900	256	19°TP104	TV
SLO1 HD	C48 / 690Mhz	6900	256	19°TP104	TV
SLO2 HD	C48 / 690Mhz	6900	256	19°TP104	TV
SLO3 HD	C48 / 690Mhz	6900	256	19°TP21	TV
Sonnenklar TV	C42 / 642Mhz	6900	256	19°TP21	TV
sonnenklar.TV HD	C25 / 506Mhz	6900	256	19°TP21	TV
SPORT1	C42 / 642Mhz	6900	256	19°TP21	TV
SR 1 Europawelle	S28 / 362Mhz	6900	256	19°TP21	TV
SR 2 KulturRadio	S28 / 362Mhz	6900	256	19°TP21	TV
SR 3 Sarlandwel	S28 / 362Mhz	6900	256	19°TP21	TV
SR Fernsehen	C23 / 490Mhz	6900	256	19°TP21	TV
SR Fernsehen HD	S28 / 362Mhz	6900	256	19°TP21	TV
SRF1 HD	C24 / 498Mhz	6900	256	19°TP21	TV
SRF2 HD	C24 / 498Mhz	6900	256	19°TP21	TV
StarParadies	C28 / 530Mhz	6900	256	19°TP21	TV
Starparadies AT	S25 / 338Mhz	6900	256	DVB-T C45-4	TV
Starparadies D	S25 / 338Mhz	6900	256	DVB-T C45-4	TV

Stimmungsgarten TV	S23 / 322Mhz	6900	256	VB-T C45-4	TV
Studio 99	C47 / 682Mhz	6900	256	VB-T C45-4	TV
sunshine live	C35 / 586Mhz	6900	256	VB-T C45-4	TV
SUPER RTL A	C29 / 538Mhz	6900	256	PPT intern	TV
SUPER RTL A	C52 / 722Mhz	6900	256	16°TPC3	TV
SWR 1 BW	S28 / 362Mhz	6900	256	16°TPC3	TV
SWR 1RP	S28 / 362Mhz	6900	256	16°TPC3	TV
SWR Aktuell	S28 / 362Mhz	6900	256	16°TPC3	TV
SWR BW HD	S22 / 314Mhz	6900	256	16°TPC3	TV
SWR Fernsehen BW	C31 / 554Mhz	6900	256	16°TPC3	TV
SWR Fernsehen RP	C22 / 482Mhz	6900	256	16°TPC3	Radio
SWR RP HD	S22 / 314Mhz	6900	256	16°TPC3	Radio
SWR2	S28 / 362Mhz	6900	256	16°TPC3	Radio
SWR2 5.1	S28 / 362Mhz	6900	256	16°TPC3	Radio
SWR3	S28 / 362Mhz	6900	256	16°TPC3	Radio
SWR4 BW	S28 / 362Mhz	6900	256	16°TPC3	Radio
SWR4 RP	S28 / 362Mhz	6900	256	16°TPC3	Radio
tagesschau24 HD	S28 / 362Mhz	6900	256	16°TPC3	Radio
TELE 5 HD Austri	C25 / 506Mhz	6900	256	16°TPC3	Radio
TELE 5 HD	C25 / 506Mhz	6900	256	16°TPC3	Radio
TELE 5	C42 / 642Mhz	6900	256	16°TPC3	Radio
TLC Austria	C35 / 586Mhz	6900	256	16°TPC3	Radio
TLC	C41 / 634Mhz	6900	256	16°TPC3	Radio
TOGGO plus	C52 / 722Mhz	6900	256	16°TPC3	Radio
TOGGO Radio	C52 / 722Mhz	6900	256	16°TPC3	Radio
Traumfrauen TV	C38 / 610Mhz	6900	256	16°TPD9	Radio
TV1 OOE NEU	C28 / 530Mhz	6900	256	16°TPD9	Radio
VISIT-X.tv	C26 / 514Mhz	6900	256	16°TPD9	Radio
Volksmusik.TV	C28 / 530Mhz	6900	256	16°TPD9	Radio
VOX	C52 / 722Mhz	6900	256	16°TPD9	TV
VOX Austria	C29 / 538Mhz	6900	256	16°TPD9	TV
VOXup	C29 / 538Mhz	6900	256	16°TPD9	TV
WDR 2 Rheinland	S28 / 362Mhz	6900	256	16°TPD9	TV
WDR 3	S28 / 362Mhz	6900	256	16°TPD9	TV
WDR 4	S28 / 362Mhz	6900	256	16°TPD9	Radio
WDR 5	S28 / 362Mhz	6900	256	16°TPD9	Radio
WDR Bielefeld	C23 / 490Mhz	6900	256	16°TPD9	Radio
WDR Dortmund	C23 / 490Mhz	6900	256	16°TPD9	Radio
WDR Düsseldorf	C23 / 490Mhz	6900	256	16°TPD9	TV
WDR Essen	C23 / 490Mhz	6900	256	16°TPD9	TV
WDR Event	S28 / 362Mhz	6900	256	16°TPD9	TV
WDR HD Aachen	C43 / 650Mhz	6900	256	19°TP108	TV
WDR HD Bielefeld	C43 / 650Mhz	6900	256	19°TP108	TV
WDR HD Bonn	C43 / 650Mhz	6900	256	19°TP108	TV
WDR HD Dortmund	C43 / 650Mhz	6900	256	19°TP108	TV

WDR HD Duisburg	C43 / 650Mhz	6900	256	19°TP108	TV
WDR HD Düsseldorf	C43 / 650Mhz	6900	256	19°TP108	TV
WDR HD Essen	C43 / 650Mhz	6900	256	19°TP108	TV
WDR HD Köln	C43 / 650Mhz	6900	256	19°TP108	TV
WDR HD Münster	C43 / 650Mhz	6900	256	19°TP108	TV
WDR Köln	C31 / 554Mhz	6900	256	19°TP108	TV
WDR Mediathek	C43 / 650Mhz	6900	256	16°TP0	TV
WDR Münster	C23 / 490Mhz	6900	256	19°TP89	TV
WDR Siegen	C43 / 650Mhz	6900	256	19°TP89	TV
WDR Siegen	C23 / 490Mhz	6900	256	19°TP89	TV
WDR Test A	C23 / 490Mhz	6900	256	19°TP89	TV
WDR Wuppertal	C43 / 650Mhz	6900	256	19°TP89	TV
WELT HD	C40 / 626Mhz	6900	256	19°TP89	TV
WELT HD Austria	C40 / 626Mhz	6900	256	19°TP89	TV
WELT	C36 / 594Mhz	6900	256	19°TP89	TV
Wir24TV	C28 / 530Mhz	6900	256	19°TP89	TV
YOU FM	C37 / 602Mhz	6900	256	19°TP89	TV
ZDF HD	S24 / 330Mhz	6900	256	19°TP89	TV
ZDF	C34 / 578Mhz	6900	256	19°TP89	TV
zdf_neo HD	S24 / 330Mhz	6900	256	19°TP89	Radio
zdf_neo	C34 / 578Mhz	6900	256	13°TP124	TV
ZDFinfo HD	S26 / 346 Mhz	6900	256	13°TP124	Radio
ZDFinfo	C34 / 578Mhz	6900	256	13°TP124	Radio